

5908997

1/27




FIG. 1




FIG. 2




FIG. 3





FIG. 4

FIG. 5




FIG. 6





FIG. 7A

FIG. 7






FIG. 9




FIG. 10




FIG. 11




FIG. 13




FIG. 14




FIG. 15





FIG. 16







FIG. 18






FIG. 20




FIG. 21





FIG. 22







FIG. 24



The image shows a graphical user interface (GUI) for a music-related application. The main window is titled "SAVE AS" and contains several sections:

- Top Section:** Includes a "SAVE AS" label, a "LATE NIGHT SESSION" button, a "RENAME" button, and a "PIANO" button (indicated by a keyboard icon). Below these are icons for "COMPACT DISC" and "FLOPPY DISK".
- Session List:** A list of "STUDIO SESSIONS" with a dropdown arrow. The sessions listed are: "SONG #1", "LATE NIGHT SESSION", "CHURCH SONG", "KID'S STUFF", and "AD LIB".
- Keyboard Layout:** A section labeled "604" showing a standard QWERTY keyboard layout with additional function keys like "SPACE", "ENTER", and "DELETE".
- Bottom Section:** Contains buttons for "CANCEL", "NEW FOLDER", "SAVE", "OK", and "CLEAR".

Labels and reference numbers are used throughout the diagram to identify specific elements:

- 603: Points to the "SAVE AS" title bar.
- 596: Points to the "LATE NIGHT SESSION" button.
- 594: Points to the "PIANO" button.
- 592: Points to the "COMPACT DISC" icon.
- 600: Points to the "STUDIO SESSIONS" label.
- 601: Points to the session list.
- 598: Points to the "RENAME" button.
- 606: Points to the "SAVE AS" label.
- 607: Points to the "CLEAR" button.
- 604: Points to the keyboard layout.
- 609: Points to the "NEW FOLDER" button.
- 611: Points to the "CANCEL" button.
- 590: Points to the "SAVE" button.
- 602: Points to the "NEW FOLDER" button.
- 610: Points to the "CANCEL" button.
- 608: Points to the "OK" button.

FIG. 26

APPROVED BY DRAFTSMAN	O.G. FIG.
	CLASS SUBCLASS




FIG. 27